


4-Door lock kit with AS80 or other Alarm System



The AS-80 should be installed according to the instructions supplied with the AS-80.
This diagram is intended to show only the connection of the AS-80 to a locking system.

AS 80 or other Alarm System



Not to Scale